


DING ALL® *The Quik Stik*

EPOXY PUTTY

**REPAIRS ALL SURFBOARDS FAST!
APPLIES ON WET SURFACES AND UNDERWATER
DRIES WHITE AFTER MIXING
INCLUDES SANDPAPER AND HAND CLEANER**

DIRECTIONS:

- For best results, clean and roughen bond area prior to application. Wash hands to prevent discoloring product.
- Twist or cut off required amount.
- To mix, moisten or wet fingers and knead till product becomes white.
- Apply to surface to be repaired (within five minutes of mixing) Force into any cracks or holes to be filled and strike off any excess material.
- When applying to damp or wet surfaces, apply pressure until adhesion begins to take affect. If material sticks to fingers apply lotion or wet fingers with water.
- For a smooth appearance, hand rub with water or place a piece of wax paper or plastic over the surface prior to hardening.
- Remove any excess material before hardening begins.
- After 20 to 30 minutes the repair will harden and be ready for sanding
- If sanding is required, use rough grit first, medium grit second, and fine grit for a wet sand finish.



WARNING:

Contains epoxy resins and amine which may cause irritation to sensitive skin. Wash hands with soap and water after use. EYE irritant. In case of EYE contact, flush with plenty of water. Contact a Physician. May be harmful if ingested. If ingested, contact a physician.

KEEP out of REACH of CHILDREN

Surf Source .Net

EPOXY REPAIR KIT